FeelTag

User Manual



低功率射頻器材技術規範

取得審驗證明之低功率射頻器材,非經核准,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。前述合法通信,指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

WARNING

「為維護隱私權・請妥適使用」

FeelTag	2-3
User Manual	Z -3

Index

01	Getting Started
02	Add Your FeelTag Locate
03	Locate Your FeelTag
04	Your FeelTag Notifications
05	When Your FeelTag Is Lost
06	Resetting FeelTag
07	Extras
80	The Fine Print
09	About Apple Find My

FeelTag	A
User Manual	T

01 Getting Started

01.1 Power On / Off:

First, turn on the Bluetooth on your phone or other device and follow the steps required to operate it:

Press the FeeTag control button for at least 3 seconds until turn it on. It should beep 3 times sound to indicate that it is powered on.

To power off, hold the same button for at least three seconds. You will hear once beep clearly to indicate that your FeeTag is powered off

Check For Updates:

01.2

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple requires the latest version of OS.

FeelTag	5
User Manual	.

O2 Add Your FeelTag

02.1 Start The App

Open Find My app on your supported iPhone.

02.2 Connect Your FeelTag

Press the function button once to power on your FeelTag.

Tap "+", then "Add Other Item".

Once your FeelTag is located, tap "connect"

Enter a name and choose an emoji for your FeelTag and tap "Continue".

Find My will ask for your confirmation to add your FeelTag to your Apple ID, Tap "Agree"

Tap "Finish" and your FeelTag will be set up and ready for use.

FeelTag	6
User Manual	0

03 Locate Your FeelTag

03.1 Find FeelTag When It's Nearby:

Open Find My app and select the "Items" tab or open the Find Items app on your Apple equipment.

Tap on your FeelTag from the list.

Tap "Play Sound" to make your FeelTag beep.

Tap "Stop Sound" to stop the beeps once you find it.

03.2 Find FeelTag's Location:

Open Find My app and select the "Items" tab or open the Find Items app on your Apple equipment.

Tap on your FeelTag from the list.

Your FeelTag's location will appear on the Map with a timestamp of when the iterm was located.

To navigate to the FeelTag's location, tap "Directions" to open on Apple Maps.

FeelTag	7
User Manual	'

04 Notifications

04.1 Enabling "Notify When Left Behind":

Open Find My app and select the "Items" tab or open the Find Items app on your Apple equipment.

Tap on your FeelTag from the list.

Under "Notifications" enable the "Notify When Left Behind" toggle.

You will receive a notification when you leave your FeelTag behind and it's no longer in range of your device.

04.2 Enabling "Notify When Found":

Under "Notifications", enable the "Notify When Found" toggle.

When your FeelTag is seen by another Find My network device, you will receive a notification of its location.

Note: "Notify When Found" can only be activated when your FeelTag is out of range.

FeelTag	0
User Manual	0

When Your FeelTag Is Lost

05.1 Enabling "Lost Mode":

Open Find My app and select the "Items" tab or open the Find Items app on your Apple equipment.

Tap on your FeelTag from the list.

Under "Lost Mode" tap "Enable"

A screen detailing Lost Mode will pop up, tap "Continue" Enter your phone number or email address and tap "Next".

You may enter a message that will be shared with the person that finds your item.

Tap "Activate" to enable "Lost Mode"

Note: When "Lost Mode" is enabled, "Notify When Found" is automatically enabled.

Note: When" Lost Mode" is enabled, your FeelTag is locked and cannot be paired to a new device.

FeelTag	Q
User Manual	,
	·

06 Resetting FeelTag

06.1 Remove The FeelTag From Find My App:

Open Find My app and select the "Items" tab.

Tap on your FeelTag from the list.

please ensure that the "Lost Mode" is disabled.

Scroll to the bottom of the screen and tap "Remove Item".

A summary will open, tap "Remove" to confirm.

06.2 Factory Reset Your FeelTag:

Press the button 5 times in a row, hear the end of the ringing chime, wait for a few seconds, hear two beeps, reset ends.

The FeelTag is now reset and ready to be paired to a new Apple ID.

FeelTag	10
User Manual	10

07 Extras

07.1 Replace The Battery:

Rotate the back shell of your FeelTag to carefully open it.

Replace the battery with a new CR2032 battery.

Carefully close the FeelTag.

07.2 Unwanted tracking:

If any Find My network accessory separated from its owner and it's seen moving with you over time, you'll be notified in one of two ways:

1. If you have an iPhone, iPad®, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.

2. If you don't have an ios device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved.

These features were created specifically to discourage people from trying to track you without your knowledge.

FeelTag	11
User Manual	''

08 The Fine Print

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure conditions without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user

FeelTag	12
User Manual	12

08 The Fine Print

is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from thatto which the receiveris connected .

FeelTag	13
User Manual	

09 About Apple Find My

The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, or Mac. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the maker of your personal item, can view its location.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc.

IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

